

# EMERGENCY EVACUATION ROUTE

Building Code: 977  
Building Name: Westside Research Office Building  
Floor Name: Basement  
Building Address: 1747 W Roosevelt Rd



Evacuation  
Assembly  
Area:

Parking Lot M which is located  
"east" of the Westside Research  
Office Building.



Stairway



Fire Extinguisher



Fire Alarm Pull Station



Exit Pathway



Storm Refuge Area



AED Location

OFFICE OF  
THE VICE  
CHANCELLOR  
FOR  
ADMINISTRATIVE  
SERVICES

